

## 700/700E 9700/9700E Series Perimeter Seals



**WARNING:** Vinyl products can expose you to chemicals including DINP Diisononyl phthalate, which is known to the State of California to cause cancer. For more information, go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

**NOTE:** Install seals before the closer. Seals installed at head will require the closer body be installed 1/4" lower on the door.

### Installation Instructions

1. Cut seal to fit.
2. Drill head piece for mounting screws, avoiding the area where the closer shoe will be located.
3. With door closed, position seal with the gasketing slightly compressed against the door.
4. Install with TEK screws provided, working from one end to the other.

700EN, 700ES, 700N, 700S, 706, 706E, 9700, 9700E, 9706E



POSITIVE PRESSURE TESTED GASKETING MATERIALS  
FOR FIRE DOORS  
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE DOORS  
RATED UP TO 3 HOURS AND WOOD-TYPE FIRE DOORS  
RATED UP TO 1-1/2 HOURS  
CATEGORY H

Smoke and Draft Control gasketing (Category H) tested to UL 1784; meets requirements of NFPA 105, IBC for use on "S" label doors. APPLIES TO 700EN, 700N, 700ES, 700S, 706, 706E, 9700, 9700E, 9706E ONLY.

700EU, 700U, 701EP, 701P, 703EV, 703V, 704EV, 704V, 705EV, 705V



POSITIVE PRESSURE TESTED GASKETING MATERIALS  
FOR FIRE DOORS  
FOR APPLICATION TO HOLLOW-METAL-TYPE FIRE  
DOORS  
RATED UP TO 3 HOURS AND WOOD-TYPE FIRE DOORS  
RATED UP TO 1-1/2 HOURS  
CATEGORY J

10.18

## Series 700/700E 9700/9700E Sellos Perimetrales



**ADVERTENCIA:** Productos de vinilo pueden exponerlo a productos químicos incluyendo ftalato de di-isononilo DINP, que el estado de California considera causante de cáncer. Para mayor información visite la página [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

**NOTA:** Instale el sello antes de instalar el cierrapuertas. Los sellos que se instalen en la parte superior requieren que el cierrapuertas se instale 1/4" más abajo en la puerta.

### Instrucciones de Instalación

1. Corte el sello a la medida.
2. Taladre el cabezal para los tornillos de montaje, evitando el área donde se ubicará el pie del cierrapuertas.
3. Con la puerta cerrada coloque el sello con la junta de neopreno ligeramente comprimida contra la puerta.
4. Instale con los tornillos TEK suministrados, procediendo de un extremo hacia el otro.

700EN, 700ES, 700N, 700S, 706, 706E, 9700, 9700E, 9706E



MATERIAL DE EMPAQUE PARA PUERTAS CORTAFUEGO SOMETIDOS A PRUEBAS DE PRESION POSITIVA, PARA USARSE EN PUERTAS METALICAS HUECAS CORTAFUEGO, CERTIFICADAS HASTA 3 HORAS Y PUERTAS DE MADERA CORTAFUEGO, CERTIFICADAS HASTA 1-1/2 HORAS CATEGORÍA H

Empaques Para Control de Humo y Corrientes de aire (Categoría H) probados de acuerdo a UL 1784; cumple con los requisitos de NFPA 105, IBC para usarse en puertas etiquetadas "S". APLICA UNICAMENTE PARA 700EN, 700N, 700ES, 700S, 706, 706E, 9700, 9700E, 9706E.

700EU, 700U, 701EP, 701P, 703EV, 703V, 704EV, 704V, 705EV, 705V



MATERIAL DE EMPAQUE PARA PUERTAS CORTAFUEGO SOMETIDOS A PRUEBAS DE PRESION POSITIVA, PARA USARSE EN PUERTAS METALICAS HUECAS CORTAFUEGO, CERTIFICADAS HASTA 3 HORAS Y PUERTAS DE MADERA CORTAFUEGO, CERTIFICADAS HASTA 1-1/2 HORAS CATEGORÍA J

10.18